



# BRUSH AND CLEARING SAW BLADES

BRAND & MODEL	GRA3 255	GRA3 300	GRA4 200	GRA4 225	GRA8 200	GRA8 225	XRT 200-20	XRT 200-25	XRT 225-20	XRT 225-25	EIA 200-20	EIA 200-25	EIA 225-20	EIA 225-25	MAXI 200-20	MAXI 200-25	MAXI 225-20	MAXI 225-25
<b>BRUSH KING</b>																		
BK 851	X	X	X	X	X	X		X		X		X		X		X		X
BK 100	X	X	X	X	X	X		X		X		X		X		X		X
<b>DOLMAR</b>																		
MS340			X	X	X	X	X			X								
MS 3200,	X	X	X	X	X	X		X		X		X		X		X		X
MS4000, MS 3300	X	X	X	X	X	X	X		X		X		X		X		X	
4010, 4510	X		X	X	X	X	X		X		X							
MS4500	X	X	X	X	X	X	X											
BC225			X		X													
BC250			X	X	X	X		X										
BC330			X	X	X	X		X		X		X		X		X		X
BC337, BC400	X		X	X	X	X		X		X		X		X		X		X
BC517	X	X	X	X	X	X		X		X		X		X		X		X
BC3300	X		X	X	X	X	X		X		X		X					
BC4000	X	X	X	X	X	X	X		X		X		X		X			
<b>ECHO</b>																		
200DA, 400BE, 302	X		X	X	X	X		X										
SRM200,250			X		X													
1500, 1501, 2100, 2200, 2201,			X		X													
2300, 2301, 240, 2410, 2500,			X		X													
2501, 2502, 2510, GT 1100,			X		X													
2110, 2601, 3100, 3110, 3400			X		X													
SRM300, 3001, 3010,	X		X	X	X	X												
SRM400, 3000, 3800, 4000	X		X	X	X	X		X		X		X		X				
CLS 4600	X	X	X	X	X	X	X		X		X		X		X		X	
<b>EFCO</b>																		
8260LAV, 8260DAV, 8260 BAV	X		X	X	X	X		X		X		X		X				
8350LAV, 8350BAV	X	X	X	X	X	X		X		X		X		X		X		X
8460BAV, 8510BAV	X	X	X	X	X	X		X		X		X		X		X		X
<b>HOMELITE</b>																		
HK-18			X		X													
HK24, ST285			X	X	X	X												
HK30, 33, HBC30, 38, 40	X	X	X	X	X	X		X			X							
D830SD, D830CB, D830SB			X	X	X	X		X		X		X		X				
ST-185, ST-385, ST-485, PBC-3600			X		X													
PBC3800, PBC4000	X	X	X	X	X	X		X		X		X		X		X		X
PLT3200, PLT3400			X	X	X	X		X		X		X		X				
PLTA-3400			X		X													
Z725CB			X		X													
Z830SB			X	X	X	X		X		X		X		X				
<b>HUSQVARNA</b>																		
22R, 24R, 25R, 26R, 125R/RJ, 132R/RJ	X		X	X	X	X	X		X		X		X					
32R	X		X	X	X	X	X				X							
36R, 39R, 235R, 240R, 245R, 125, 132	X		X	X	X	X	X		X		X		X					
250RX, 265RX, 235, 240, 245, 250	X	X	X	X	X	X	X		X		X		X		X		X	
225RJ, 225R, 225RD	X		X	X	X	X	X		X		X		X					
232R, 240RBD	X	X	X	X	X	X	X		X		X		X		X		X	
120 SERIES, 227	X		X	X	X	X	X				X							
<b>JOHN DEERE</b>																		
350G, 450G	X		X	X	X	X		X		X		X						
240G, 260G, 300G			X		X													

# BRUSH AND CLEARING SAW BLADES



BRAND & MODEL	GRA3 255	GRA3 300	GRA4 200	GRA4 225	GRA8 200	GRA8 225	XRT 200-20	XRT 200-25	XRT 225-20	XRT 225-25	EIA 200-20	EIA 200-25	EIA 225-20	EIA 225-25	MAXI 200-20	MAXI 200-25	MAXI 225-20	MAXI 225-25
<b>ONSERED</b>																		
200, 220, 260, GT21L, 22L, 24L			X	X	X	X												
300, 320B	X	X	X	X	X	X												
400, 450, 420B, 460B, GR36, GR41, GR44	X	X	X	X	X	X		X		X		X		X				
GR32, GR50	X	X	X	X	X	X	X		X		X		X		X			
BP2040, GR2026, GR2032	X	X	X	X	X	X	X		X		X		X		X			
GR2032, GR2036	X	X	X	X	X	X	X		X		X		X		X			
RS40, RS44, RS45	X	X	X	X	X	X												
RS51, JGR26L			X		X		X				X							
JGR26D, JGR36	X	X	X	X	X	X	X		X		X		X		X			
JR544, JR551, JGR32L, JGR32D	X	X	X	X	X	X	X		X		X		X		X		X	
<b>MARUYAMA</b>																		
BC201			X															
BC200, 260, 260H	X		X	X	X	X												
BC320, 320H, 402M	X		X	X	X	X		X		X		X		X		X		
BC420H			X		X													
480, BC402H, BC500H	X	X	X	X	X	X		X		X		X		X		X		
BC2300, BC2600, BC3200			X	X	X	X												
BCGX22, BCGX31, BCL2250			X	X	X	X												
<b>MCCULLOCH</b>																		
eager beaver series		X		X														
PRO MAC SERIES			X		X													
PM111, PM1111			X	X	X	X	X				X							
MAC2827, PROSCPR. 285	X		X	X	X	X	X		X		X		X					
MAC3227, 3227HD, PROSCPR.32HDS, PROMAC IV HD	X	X	X	X	X	X	X		X		X		X					
TITAN 2310, 2360			X		X		X											
TITAN 2560, 2565			X	X	X	X	X											
TITAN 3000, 3900	X	X	X	X	X	X		X		X		X		X				
<b>OLYMPYK</b>																		
220, 260, 721			X	X	X	X		X		X		X		X				
300, 727T, 400, 450, 733T, 740	X	X	X	X	X	X		X		X		X		X				
320LAV, 320 BAK, 420 BAV, 460BAK, 8510 BAV, JET401	X	X	X	X	X	X		X		X		X		X		X		X
B200			X		X		X											
8260 series, 8350, 8460, 8851			X		X													
<b>POULAN</b>																		
195,117			X		X		X		X		X		X					
185			X	X	X	X	X		X		X		X					
200	X	X	X	X	X	X	X		X		X		X		X		X	
<b>RED MAX</b>																		
BC260, BC261, BC262, BC340	X	X	X	X	X	X		X		X		X						
BC341, BC440, BC441, BC2300	X	X	X	X	X	X		X		X		X						
BC2600	X	X	X	X	X	X		X		X		X						
BC2001DL, BC2300DL			X	X	X	X												
BC2600DL	X		X	X	X	X		X				X						
BC342DL, B442DWM	X	X	X	X	X	X		X		X		X			X			X
BC340DL, BC430	X	X	X	X	X	X		X		X		X		X		X		X
BT200, BT220, BT2000			X		X													



# BRUSH AND CLEARING SAW BLADES

BRAND & MODEL	GRA3 255	GRA3 300	GRA4 200	GRA4 225	GRA8 200	GRA8 225	XRT 200-20	XRT 200-25	XRT 225-20	XRT 225-25	EIA 200-20	EIA 200-25	EIA 225-20	EIA 225-25	MAXI 200-20	MAXI 200-25	MAXI 225-20	MAXI 225-25
<b>ROBIN</b>																		
NB04-2, NB30, NB31, NB351	X		X	X	X	X		X		X		X						
NB411	X		X	X	X	X		X		X		X						
NBT415, NB02, NB27, NB211			X	X	X	X		X		X		X						
NB16, NB23, NBF171, NB252			X	X	X	X												
<b>SEARS</b>																		
79622, 79623	X		X	X	X	X		X		X								
<b>SHINDAIWA</b>																		
C-25			X	X	X	X		X		X								
C-27	X		X	X	X	X		X		X		X		X				
C-230, C250			X	X	X	X		X		X		X						
C35, BP35	X		X	X	X	X		X		X		X		X		X		
B40, B45, RC45	X	X	X	X	X	X		X		X		X		X		X		X
<b>SOLO</b>																		
400			X	X	X	X		X		X								
124, 126			X	X	X	X	X		X									
127			X		X		X			X		X						
130	X		X	X	X	X	X		X		X		X					
134,137,140	X	X	X	X	X	X	X		X		X		X		X			
200, 300, 120			X		X													
<b>STIHL</b>																		
FS81, FS86, FS96	X	X	X	X	X	X		X		X		X		X		X		
FS150			X		X													
FS353, FS410	X	X	X	X	X	X	X		X		X		X		X		X	
FS44, FS66, FS81			X		X													
FS44, FS61, FS65, FS80, FS90, FS96																		
FS106, FS36, FS40	X		X	X	X	X		X		X		X		X				
FS88AV, FS108, FR106	X		X	X	X	X		X		X		X		X				
FS160, FS180, FS200	X		X	X	X	X	X		X		X		X		X		X	
FS220, FS280, FS360	X	X	X	X	X	X		X		X		X		X				
FS420, FS74, FS76			X	X	X	X	X		X		X		X					
<b>TANAKA</b>																		
TBC322, TBC373	X		X	X	X	X		X		X		X		X		X		X
AST5000, TBC200, SERIES			X	X	X	X		X		X		X		X		X		X
TBC420, TBC2211,			X	X	X	X		X		X		X		X		X		X
TBC2510, TBC3010, TBC4501			X	X	X	X		X		X		X		X		X		X
ATS7000S, TBC 4500, TBC 200																		
TBC2110			X		X													
TBC240, 250, 265, 300	X		X	X	X	X		X		X		X		X				
TBC 325, 355, 400, 425, 422C, 500	X	X	X	X	X	X		X		X		X		X		X		X
<b>WEED EATER</b>																		
XT100, XT125	X		X	X	X	X		X		X		X						
1000	X		X	X	X	X		X		X		X						
PRO150	X		X	X	X	X		X		X		X						
XR90, XR95,	X		X	X	X	X		X		X		X						
YP160, YP200	X		X	X	X	X		X		X		X						
GT118			X	X	X	X												
GT118KT, XT85T			X	X	X	X		X		X								
GT119T			X		X		X		X									
YP130A, YP145			X	X	X	X												
XT125KT, XT125T, XT125R			X	X	X	X												
XR200			X					X										